

CARE AND MAINTENANCE OF PRINTED DIBOND

Manufacturing Process

Dibond plates are made from a high grade Aluminium Sheet material, after shaping the plates on our CNC router a laminated vinyl graphic is applied to the panel.

This product has proved to be an excellent outdoor solution; however, as with all outdoor signage there is a degree of maintenance needed to keep the signs and plaques looking their best.

Procedure

Ideally monthly, but at 2-3 times per year, all Dibond should be washed with mild detergent and water to remove any surface marks, at the same time being assessed for any damage or degradation that may require treatment.

Graffiti

An "Anti-Graffiti" protection can be applied to Dibond panels at the manufacturing stage. However, this can be quite expensive and therefore quite often not cost effective to do so.

Vandalism

Physical damage, scratches, gouges and paint graffiti are usually irreparable. A replacement panel is often the only solution, contact Pinseeker for more information.

Indemnity

Pinseeker UK Ltd cannot be held responsible whatsoever for any damage caused to the posts by outside influences such as fertiliser, Chemicals, vandalism, or a lack of maintenance.

Limitations

Localized ground & climate conditions can vary greatly and must be considered by the installer for the effects on Dibond products.

This information is for general guidance only and all installations are the direct responsibility of the club or installer.

No responsibility or liability can be accepted by Pinseeker (UK) Ltd.



**Dangerous
substances**

Warning: Since some fertilisers do have harmful ingredients it is wise for the Dibond plates to be wiped clean after any application of fertilisers onto the course.

Warning: It is essential that any bird droppings are removed from the signs as quickly as is practically possible, as at certain times of the year they can be very acidic causing damage surface damage.

